










EXPLANATION




Perched water—Approximate area




Fault—Dashed where approximately located, dotted where concealed



Boundaries—
Mojave ground-water basin (approximate)—
 Subarea
Mojave River drainage basin
Mojave Water Agency management area



Water-table contour—Shows altitude of water table (Spring 2002). Contour interval, in feet, is variable; dashed where approximately located, queried where uncertain. Hachures indicate depression. Datum is NAVD 88




Well—
 Top number is abbreviated State well number.
 Bottom number is altitude of water level, in feet above NAVD 88 (Spring 2002).
 Asterisk (*) indicates perched water



Generalized direction of ground-water flow

[Back to plate 1](#)



EXPLANATION

- Fault**—Dashed where approximately located; dotted where concealed

Boundaries—

Morongo ground-water basin (approximate)—
Subbasin boundary

Warren ground-water subbasin boundary

Water-table contour—Shows altitude of water table (2002). Contour interval, in feet, is variable; dashed where approximately located, queried where uncertain. Hachures indicate depression. Datum is NAVD 88

Generalized direction of ground-water flow

Well—
Top number is abbreviated State well number. Bottom number is altitude of water level, in feet above NAVD 88 ()

Artificial-recharge sites

Back to
plate 1